



Wa

BoW1

W2Aw

Dww bL Dww bR

Dww1 1R 1L Dww2 2R 2L

FW22 FW24  
UFSaW

SBhf II

SBhf I

FW17  
FW18  
FW19  
FW90

FW86  
FW85  
FW84  
FW89  
FW88  
FW87

Dww3 3R 4L 4R Dww4  
Dww CL Dww CR

Si 1

FW21 FW23

BoW2

Aufenthaltsschaltung SI

SRK Aufenthaltsschaltung

W1Aw

BoW3

W1a

FW82  
FW83

W1

FW81

7  
8